

DRY ICE MACHINE INSTRUCTIONS

MAKE SURE THE RED HANDLED DRAIN TAP ON THE BASE OF THE MACHINE IS IN THE CLOSED POSITION.

USING A BUCKET OR HOSE FILL WITH CLEAN WATER THROUGH THE HINGED GATE ON THE TOP OF THE MACHINE TO APPROX HALF WAY UP SIGHT GLASS (THIS MEANS THE MACHINE WILL BE 1/4 TO 1/3 FULL). **DRY UP ANY SPILT WATER ON OR AROUND MACHINE – REMEMBER WATER AND ELECTRICITY DON'T MIX!!!!**

- PLUG INTO THREE PHASE POWER SUPPLY.
- TURN THE MACHINE ON – THIS WILL TURN ON AN INTERNAL HEATING ELEMENT TO HEAT THE WATER (WATER TEMPERATURE IS CONTROLLED BY A THERMOSTAT). LEAVE FAN OFF. THIS WILL TAKE 15 TO 20 MINS.
- THE EFFECT WILL BE THE BEST IF YOU CAN CONTAIN THE FOG. BUILD A FENCE AROUND THE EDGE OF THE SHOOTING AREA. (BLACK BUILDERS PLASTIC WORKS A TREAT.) BETWEEN KNEE AND WAIST HEIGHT IS SUFFICIENT.
- **NOW'S A GOOD TIME TO READ THE SAFETY INSTRUCTIONS THAT ARE RELEVANT TO THE DRY ICE PELLETS!** PUT ON PROTECTIVE GLOVES AND SAFETY GLASSES, AND USE A CONTAINER TO SCOOP OUT THE DRY ICE FROM THE BOX. THIS STUFF WILL GIVE YOU A NASTY BURN IF EXPOSED TO UNPROTECTED SKIN!
- WHEN WATER IS HOT (APPROX 15 MINS) SPREAD A COUPLE OF SCOOPS FULL OF DRY ICE PELLETS IN INTERNAL BASKET AND LOWER UNTIL IT JUST SITS ON TOP OF WATER. (DO NOT SUBMERGE!! THE HEIGHT CAN BE LOCKED WITH VICE-GRIPS ON SHAFT). THE BEST DRY ICE FOG IS PRODUCED WHEN DRY ICE PELLETS SIT JUST ON THE SURFACE OF WARM TO HOT WATER.
-
- TURN ON FAN AND ADJUST SPEED TO DESIRED EFFECT. VARIOUS FOG EFFECTS CAN BE PRODUCED BY VARYING THE AMOUNT OF PELLETS IN THE BASKET, THE HEIGHT OF THE PELLETS IN THE WATER, AS WELL AS THE FAN SPEED
- **DO NOT PUT YOUR HEAD IN THE CLOUD OF SMOKE – THIS IS CARBON DIOXIDE GAS – THERE IS NO OXYGEN IN THERE. DRY ICE SMOKE IS AN ASPHYXIANT – IF YOU ARE STUPID ENOUGH TO PUT YOUR HEAD IN THE WHITE CLOUD YOU WILL EVENTUALLY PASS OUT FROM LACK OF OXYGEN. USE YOUR HEAD – IT LOOKS ALL HEAVENLY BUT CAN BE HELLISH IF ABUSED.**
- PLEASE KEEP AN EYE ON THE WATER LEVEL AND REPLENISH AS NECESSARY
- PLEASE EMPTY WATER THROUGH BOTTOM DRAIN TAP BEFORE RETURNING.

**PLEASE CALL Texas Productions FOR MORE INFORMATION
9966 5554**

NB. It is a condition of hire that all persons hiring this machine do so at their own risk. Texas Productions Pty Limited, The Hell Team and their employees are absolved from liability for damage to the hirer and associated production personnel, property and equipment, no matter whether for negligence or any other basis and no matter whether such injury or damage be foreseeable or howsoever such injury or damage be caused. Any damage to the machine and subsequent loss of income, is payable in full by the hirer.